

Acer	1339, 4143
Admiral	0463, 3485, 4111, 4221, 0179, 1555, 1891
Aiffarty	3717, 3577
Aitron	4179
Aiko	1579, 2132
Aiwa	1362
Akal	1675, 1385, 0672, 0765, 1689
Akawa	3391
Alaron	0179
Albide	0672
America	4179
America Action	0180
Ameisonic	4179
Anam	0180
AOC	1589, 4170, 1365, 4184, 4185, 1089, 4101, 1862, 2014, 2087
Apex Digital	2397, 0765, 4179, 1991
Ario	2397
Asus	3340
Atvio	3638, 3636, 4179, 3654, 3657
Audinac	0180, 0391
Audiovox	1865, 0180, 0451
Aumark	0060
Auria	2087, 2014
Aventura	0171
Barco	0054
Baysonic	0180
BenQ	1315, 1032
BGH	4029, 4070, 0898, 2414, 0876, 3485
Bluesens	2735
Blue Light	3655
Blue Sky	2153, 3997, 0054, 1372
Bluesky	2153, 3997, 0054, 1372
Boige	1696
Bradford	0180
Britania	2414
Broksonic	0463, 1911, 0642
Carver	0054, 0170
CC	3782, 4091, 3706, 0054, 0451, 0329
Celera	0765
Champion	1362
Changhong	3814, 0765
General	0451
Citizen	0060
Clarion	0180
Coby	3478, 2306, 2340, 1538, 2348
Commercial Solutions	1447
Contec	0180
Contex	4053
Continental	1682, 2157, 0858, 3321, 4179
Continental Electic	3321
Coradir	2844
Craig	0180
Crosley	0054
Crown	0180, 0672
Crown Mustang	0672, 0898
Curtis	3577, 3895, 2352, 2397, 3939, 1991, 2003, 3636, 1326, 3382, 3717
Curtis Mathes	0060, 0451, 0054, 0145, 1959
CXC	0180
Cyton	1326, 2003
Daewoo	0451, 0661, 0672, 1816
Daytek	3651, 2241
Demon	0145
Denstar	0628
Digitrex	4207
Disney	0463
Durabrand	0463, 0171, 1034, 0178, 0180, 1878
Dynex	2049
Ectec	0391
Electrograph	1755
Electrohome	0463, 1670
Element	3579, 1687, 2183, 2064
Emerson	1864, 1963, 0171, 0463, 0180, 0179, 0178, 1911, 0451, 2183, 3579
Enross	0876
Envision	1589, 1365, 2087, 2014
Epworth	1362
EQD	2014, 2987
EQD Atria	2014, 2087
ESA	0171, 1963
Fair Mate	1326
Favi	3382, 2676
Fisher	1362
Fluid	2964

Frigidare	2231
Fujitsu	0179
Funa	0171, 0180, 1963, 0179, 1864
Futurated	0180
Gateway	1755, 1756
GE	0451, 1447, 0178, 0765
General Electric	0451, 1447, 0178, 0765
GFM	0171, 1963, 1864, 1865
Global	4177
Go Video	0060
GoldStar	0178
GPX	0179
Gradiente	1369, 1804, 0145, 0170
Grundig	0672, 1372
Grumpy	0179, 0180
Haier	1749, 3382, 2293, 3620, 1034
Halfmark	0178
Hanspree	1348, 1745
Harley Davidson	0179
Hamaav/Kardon	0054
Harvard	0180
H-Buster	3620, 3419
Helios	0865
Hello Kitty	0451
Hewlett Packard	1089
Hikato	0628
Himitsu	4179, 0180, 0628, 0779
Hisense	2183, 2098, 4179, 3382, 4029, 3620
Hitachi	1643, 1576, 3697, 3382, 0145, 1345, 1457, 1682, 1667, 2132, 2676
Hitech	1682, 1814, 4179, 4183
HP	1089
Hyundai	3418, 1814
Imperial	4183
Infinity	0054
Insignia	2049, 1326, 0463, 1423, 0171, 1385, 1963
IRT	0628, 0451, 0098
iSymphony	3382
JBL	0054
Jensen	1326
JVC	1774, 2321, 0731, 0463, 1670, 4070
KC	4182
KDS	1687
KFC	0180
Ken Brown	4221, 1321, 4444
Kiland	4430
Kioto	0054, 0628, 0706, 0785
KIH	0765
Kolin	1240
Konka	0628, 1385, 1939
Kreissen	0876
KTV	0180
Legend	2397
Lexus	3638, 3654, 3657
LG	1423, 0178
LXI	0156, 0178, 0054
M&S	0054
MAG	1687
Magnavox	0054, 2597, 1963, 1454, 0706, 0179, 0171, 1365, 1755, 1867, 2676
Magnum	4179
Marantz	0054, 1454
Master-G	3321, 3419, 4177
Maxent	1755
Megatron	0145, 0178
Memorex	0463, 1911, 0179, 1670, 0178, 0060, 0150, 1687
MGA	0150, 0178
Microsonic	1326, 2483, 3419, 3679, 4235
Miray	2414, 3847, 4176, 4177, 1814, 0785, 3485, 4178, 0898, 3309, 3321
Misaki	0171
Mitsubishi Electric	0150, 1797, 0178
Mitsui	4179, 1123, 3658, 1385, 3638, 3652, 3654, 3656, 3657
MTC	0060
Multitech	0180
NAD	0156, 0178
Nacki	1540, 2357
Naxa	2104, 2735, 2397, 3382
NEC	1797, 1704, 0876, 2293, 0170
NetTV	1755
New Acoustic Dimension	0156, 0178
NEX	1814
Best Electronics	2183

Nikko	0178, 0156
Nimbro	2104
Nisato	0391
Noblex	1362, 3697, 4029, 0430, 0898, 2003, 3803, 4205
Norcent	1365, 1589, 1089, 4179, 1745
Nordmende	3419, 3861, 3134, 3327, 3767, 3835
Nuffison	2397
OKI	1667
Olevia	1610, 1240, 1144
Onwa	0180
Optimus	1457
Orion	0463, 1911, 3485, 0179, 2031, 3540
Panasonic	1480, 0054, 0060, 0145, 0150, 0156, 0178
Panavideo	3679
Panavox	0898, 4057
PARK	2104
Philco	4177, 3022, 0145, 2414, 4178, 1362, 3697, 0054, 0171, 1963, 0179, 0463, 0786, 1911
Philips	1867, 1454, 2597, 0054, 0171, 1963, 1365, 1589
Pioneer	1457
Planar	1457, 1589
Polaroid	1538, 1385, 1687, 1991, 1327, 0765, 0865, 2117, 1326, 2120, 1524
Portland	0451
Prima	1749
Proscan	1447, 3577, 3382, 2183, 3717, 3332, 3895, 3636, 3939, 2746
Proton	0178
Proview	1687
Punktal	0642, 2687
QuantumFX	2337
Qasar	0810, 4207
RCA	2414, 2746, 1447, 3577, 3382, 2932, 3717, 3332, 2183, 4394, 1452, 2403, 1959, 3419, 3636, 3895, 1385, 1911, 3939, 0060, 0090, 1670
Realistic	0180, 0178
Recco	3847, 0706, 0898, 1814, 2414
Sampo	1755
Samsung	2051, 1959, 0060, 0329, 0587, 0178
Sankey	2964
Sansai	0451
Sansui	0463, 3540, 1911, 1670, 4053, 4442, 0171, 3579
Sanyo	1362, 1480, 0054, 0088, 3697, 3861
Sceptre	0810, 2337
Scotch	0178
Scott	0178, 0179, 0180
Sears	0054, 0156, 0179, 0171, 0178
Seiki	2964, 3579, 3560, 0178
Semivox	0180
Semp	1743, 0156
Semp Toshiba	1743, 3793, 0156
Sens	1749, 1865
Serie Dorada	3814, 4221
Sharp	2360
Signature	0054
Signature2000	0054
Silo	4182, 0810
Silo Digital	4182, 0810
Sirageon	4057
Soneview	4179
Sony	0810, 1317, 1085
Soundesign	0178, 0180, 0179
Space Tek	1696
Spectroniq	1687
Speler	4105, 4041
Squareview	0171
SSS	0180
Starlite	0180
STI	3293
SunBoteTV	2337, 1610
Superscan	1963, 0171
Supersonic	2397, 2104
Suzuki	4434
Suzuki Time	4434
SVA	0587, 0865, 4179, 1963
Sylvania	0171, 0054, 1963, 1864, 0587
Symphonic	0171, 1963, 0180

Syntax	1610, 1240, 1144
SZK	4434
Taki	1540
Tatung	1756
TCL	2414, 4177, 3847, 4176, 3047, 0898, 2403, 4178
Technol Ace	0179
Teknika	0179, 0054, 0180, 0060, 0150
Telefunken	2414, 0898
TNK	0178
Tonomac	4221, 4444
Tophouse	0180
Tosako	1540, 2357, 1385
Toshiba	1524, 0156, 3134, 1743, 1704, 1959, 1369, 0060, 2676
TVS	0463
Ultra	0391
Upstar	4182, 4405
Venturer	1865
Vidikron	0054
Vidtech	0178
Viewsonic	2014, 3706, 2087, 1330, 1755, 2049, 0885, 1542, 1578, 1742, 1365
Viore	2352, 3382, 2104, 2397
VisionQuest	2397
Vivitek	1369
VIZO	1758, 2707, 1756, 0885
Vyon	3418
Waycon	0156
Westinghouse	1712, 3579, 3382, 0885, 2293, 3470, 2397, 0451, 0463
White Westinghouse	0451, 0463
Wyse	1365
Xococo	1749
Zenith	0178, 1911, 1423, 0145, 1365, 0463
Zonda	0698, 0779